



Inside Mount Installation

1. measure actual top (!) width of the opening
2. measure actual height of the opening
3. deduct 1/4 inch in width

German
Shades[®]
...window fashion reinvented