



Wall Mount Installation

1. measure the actual width of the opening
2. measure the actual height of the opening
3. add at least 2 inches in height; 3 inches for total clearance
4. add at least 1 inch each side (!) in width to cover the edges of the openings

**German
Shades[®]**
...window fashion reinvented